



LEGEND:

- ① HUNTER DRIPLINE (HDL) PER PLAN
- ② AIR RELIEF VALVE IN VALVE BOX
- ③ PLD OR PLD-LOC FITTINGS TYP.
- ④ FLUSH POINT (PLD-BV) IN SUBTERRANEAN BOX PER PLAN
- ⑤ LANDSCAPE ISLAND CURB
- ⑥ ECO-INDICATOR ON SWING ARM
- ⑦ DRIP CONTROL ZONE KIT PER PLAN

NOTES

AIR RELIEF VALVE (PLD-AVR) INSTALLED IN VALVE BOX AT OPTIMAL HIGHEST POINT FROM CONTROL ZONE KIT. MULTIPLE AIR RELIEF VALVES MAY BE NEEDED TO ACCOMMODATE DIFFERENCES IN GRADE.

ECO-INDICATOR TO BE INSTALLED AT OPTIMAL FURTHEST POINT FROM CONTROL ZONE KIT IN CLEAR VIEW WHEN POPPED UP.

FLUSH POINT TO BE INSTALLED AT OPTIMAL FURTHEST POINT FROM CONTROL ZONE KIT TO ALLOW FOR MAXIMUM DEBRIS FLUSH IN SYSTEM.

AS SPECIFIED

AS SPECIFIED

HARDSCAPE



HUNTER DRIPLINE - PARKING LOT ISLAND

Hunter HM.HDL.03

NOT TO SCALE